

# Anvil Double Sided Desk

## Assembly Instructions

**Tools Required:** Powered Screwdriver




# Anvil Double Sided Desk


## Assembly Instructions

---

- To prevent possible scratches or damage, assemble the desk upside down on a soft surface such as a blanket, carpet or packaging.
- Attach legs to the top assembly by using bolts, spring washer, flat washer. Tighten using the allen wrench.




**Recommended  
2-person Step**




### Step 1

Assemble frames & rails together, loosely (1 turn from tight).




### Step 2

Assemble screen brackets to frame, loosely (1 turn from tight).




### Step 3

Fix desk top with 5mm overhang over metal frame. Where desk top butts together, make sure these are fitted tight.




### Step 4

Slide centre screen pole over bracket. Carefully remove end seal on centre screens & fit screen between end brackets & screw self tappers to fix screen tightly.




### Step 5

Attach centre screen end seal and top cap with soft non-marking mallet.




### Step 6

Attach screens to centre pole with top slug connectors.




### Step 7

Mark out end of return screens on desk.




### Step 8

Remove return screen and fix bracket in place. As an alternative to screws, use 3M double sided tape to fasten return screen bracket to desk top.




### Step 9

Remove return screen end seal, and attach screen to bracket with self tapper screws.




### Step 10

Attach return screen end seal and top cap with soft non-marking mallet.




### Step 11

Install all top caps simultaneously down all together gently tapping with a soft non-marking mallet.




### Step 12

If for whatever reason you have to remove the top seal, then to refit, slightly arc in the middle, placing the 2 ends into location, & gently tap down.




### Step 13

Fit power/data rails with screws into frame rail.




### Step 14

Fully tighten all rails to frame screws, & then screen bracket screws.



### Step 15

Attach cable trays with screws provided.



### Completed

