# **Agile - Winder**

# Assembly Instructions - Single Sided, Double Sided, Returns

Tools Required: Powered Screwdriver



# **Agile - Winder**

#### **Assembly Instructions**

#### **Contents**

Winder <b>Single</b> Sided Desk	Page 4
Winder <b>Single</b> Sided Desk with Desk Hung Screen	Page 16
Winder <b>Single</b> Sided Desk with Cable Tray	Page 24
Winder <b>Double</b> Sided Desk	Page 29
Winder <b>Double</b> Sided Desk with Screen	Page 46
Winder <b>Double</b> Sided Desk with Cable Tray	Page 51
Winder <b>Return Right</b> Hand	Page 58
Winder <b>Return Right</b> Hand <b>Single</b> Sided Desk	Page 62
Winder <b>Return Right</b> Hand <b>Double</b> Sided Desk	Page 65
Winder <b>Return Left</b> Hand	Page 68
Winder <b>Return Left</b> Hand <b>Single</b> Sided Desk	Page 72
Winder <b>Return Left</b> Hand <b>Double</b> Sided Desk	Page 75



## **Agile - Winder**

#### **Assembly Instructions**

#### **IMPORTANT**

Please carefully read the assembly instructions and direction for use prior to instalment, use and maintenance of the table frame to gain a complete understanding of its contents. It provides you with important information about the safety, use, installation and maintenance of the table.

WARNING: FAILURE TO COMPLY WITH OR OBSERVE ALL ASSEMBLY, SAFETY AND OPERATION INSTRUCTIONS REGARDING THE USE OF THIS PRODUCT MAY RESULT IN SERIOUS BODILY INJURY.

#### **SAFETY**

- The table must be used in a safe manner. Inappropriate use may cause damage to the table and/or cause bodily harm to the user or persons nearby.
- Do not use the table frame to lift people.
- Please retain this operation manual and pass it on to any future owner.

#### **USAGE**

- The height-adjustable table is designed for use in dry work environments only.
- The table height is infinitely adjustable within its height range so that it can be set to the user's most ergonomic working height. The user should seek professional help to establish their optimum working height.
- The table has been designed as a devise to elevate the users work surface and associated office peripherals. Do not use the table frame for any other purposes than that which it has been designed for. Any other use is at user's own risk!
- Do not crawl, lie or move around under the table frame, and do not sit or stand on the table frame.
- CHILDREN should only use the table when supervised by adults.
- Liability: The manufacturer accepts under no circumstances warranty claims or liability claims for damages arising from improper use or handling of the table frame other than that described in this operation manual.

#### **SET UP AND INSTALLATION**

Assemble the table frame according to the following pages in this assembly instructions guide.

- Place the table in a safe distance from window frames, radiators, furniture etc. so that persons cannot become trapped.
- Level the table with the adjustable feet ensuring that the table is stable.

The table is now ready for use.

#### **MAINTENANCE**

- The table does not require any maintenance by the user
- The table is only to be cleaned with a wrung cloth.


#### **TECHNICAL DATA**

Height Range: 680-1130mm includes worktop Speed: Up and down speed 5mm/turn Weight Rating: 100kg



#### **Assembly Instructions**

#### **Parts**






1 x L&R Support Bar Pair



1 x Winder



4 x Levelling Foot



8 x M8x25



8 x M8x10



6 x ST5.0x23



2 x M8x10





2x Washer  $2 \times ST3.9x12$ 



**Assembly Instructions** 


# Step 1 2 x M8x10 2 x M8x10 2 x Washer


**Assembly Instructions** 

## Step 2



4 x M8x10








**Assembly Instructions** 

#### Step 3



4 x Levelling Foot





#### **IMPORTANT!**

REFER TO PAGE 16 FOR INSTALL OF SCREEN




8 x M8x25








**Assembly Instructions** 





**Assembly Instructions** 






**Assembly Instructions** 


## Step 6



6 x ST5.0x23





**Assembly Instructions** 



**Assembly Instructions** 

#### **Positioning of Winder Handle**






# Agile - Winder Handle from Right to Left Operation

**Assembly Instructions** 

#### Step 1






# Agile - Winder Handle from Right to Left Operation


**Assembly Instructions** 

#### Step 2



**Assembly Instructions** 


## Completed





#### **Assembly Instructions**

#### **Parts**







2 x M8x25




4 x ST5.0x23



2 x Stabilizing Bracket


**Assembly Instructions** 

#### Step 1






**Assembly Instructions** 



**Assembly Instructions** 








**Assembly Instructions** 

## Step 4




2 x M8x25






**Assembly Instructions** 





**Assembly Instructions** 


#### Step 6





**Assembly Instructions** 

#### **Completed**





**Assembly Instructions** 

#### **Parts**











4 x M6x10

4 x M5x6

2 x SSD Tray Mounts


1 x SSD Tray

**Assembly Instructions** 

#### Step 1



4 x M6x10






**Assembly Instructions** 

#### Step 2




4 x M5x6






**Assembly Instructions** 


#### **Step 1 - Power & Data Plate**














**Assembly Instructions** 


#### **Step 2 - Power & Data Plate**





#### **Assembly Instructions**


#### **Parts**





#### **Assembly Instructions**

#### **Parts**















2 x Winder

4 x Levelling Foot

16 x M8x10

x10

4 x M8x10

4 x Washer

20 x M5x10

12 x ST5.0x23

#### **Assembly Instructions**

# Step 1 8 x M8x10 4 x M8x10 4 x Washer




**Assembly Instructions** 

## Step 2



8 x M8x10






**Assembly Instructions** 

## Step 3



4 x Levelling Foot




**Assembly Instructions** 

## Step 4



16 x M5x10






**Assembly Instructions** 

## Step 5




4 x M5x10






**Assembly Instructions** 

## Step 6




































#### **Assembly Instructions**

#### **Positioning of Winder Handle**






#### Agile - Winder Handle from Right to Left Operation






#### Agile - Winder Handle from Right to Left Operation










**Assembly Instructions** 

#### **Parts**



**Assembly Instructions** 


#### Step 1





2 x M8x20


2 x Screen Bracket



**Assembly Instructions** 

# Step 2 4 x M5x15








**Assembly Instructions** 


#### Completed






**Assembly Instructions** 

#### **Parts**



**Assembly Instructions** 


#### Step 1






**Assembly Instructions** 

#### Step 2













**Assembly Instructions** 


#### Step 4




**Assembly Instructions** 

#### **Step 1 - Power & Data Plate**










**Assembly Instructions** 


#### **Step 2 - Power & Data Plate**





**Assembly Instructions** 

#### **Parts**




**Assembly Instructions** 

#### Step 1



2 x M8x10




**Assembly Instructions** 

#### Step 2



2 x M8x10



#### **Assembly Instructions**


#### Step 3





2 x Levelling Foot

4 x M8x25




#### **Agile - Winder Return RH Single Sided Desk**

**Assembly Instructions** 

#### Step 1



5 x ST5x23




#### **IMPORTANT!**

REFER TO PAGE 4 OF THE INSTRUCTIONS TO ASSEMBLE THE WINDER SINGLE SIDE DESK FRAME AND TOP.

#### **Agile - Winder Return RH Single Sided Desk**

**Assembly Instructions** 


#### Step 2




#### **Agile - Winder Return RH Single Sided Desk**

**Assembly Instructions** 

#### **Completed**




#### **Agile - Winder Return RH Double Sided Desk**






#### **Agile - Winder Return RH Double Sided Desk**



#### **Agile - Winder Return RH Double Sided Desk**

**Assembly Instructions** 


#### **Completed**





#### **Assembly Instructions**

#### **Parts**




**Assembly Instructions** 

#### Step 1



2 x M8x10






**Assembly Instructions** 

#### Step 2



2 x M8x10





**Assembly Instructions** 

## Step 3 2 x Levelling Foot 4 x M8x25




#### **Agile - Winder Return LH Single Sided Desk**

**Assembly Instructions** 

#### Step 1



5 x ST5x23



#### **IMPORTANT!**


REFER TO PAGE 4 OF THE INSTRUCTIONS TO ASSEMBLE THE WINDER SINGLE SIDE DESK FRAME AND TOP.



#### **Agile - Winder Return LH Single Sided Desk**

**Assembly Instructions** 


#### Step 2



#### **Agile - Winder Return LH Single Sided Desk**

**Assembly Instructions** 

#### **Completed**






#### **Agile - Winder Return LH Double Sided Desk**

**Assembly Instructions** 

### **IMPORTANT!** Step 1 REFER TO PAGE 29 OF THE INSTRUCTIONS TO ASSEMBLE THE WINDER DOUBLE SIDE DESK FRAME AND TOPS. 5 x ST5x23

#### **Agile - Winder Return LH Double Sided Desk**



#### **Agile - Winder Return LH Double Sided Desk**

**Assembly Instructions** 

#### **Completed**

